



AyA doors and drawers can be adjusted to help maintain the proper alignment of fronts over time as cabinets settle with regular use. This guide outlines the steps to remove doors and drawer boxes and make these adjustments depending on the type of hinge and/or drawer box selection made.

Soft Close Door Hinges

To remove cabinet doors, locate the small lever located at the back of the hinge and push forward to release the hinge from its bracket.

To adjust, remove the cover cap to reveal the mechanisms and follow the steps below:

Vertical (Up/Down)	Horizontal (Left/Right)	Depth (In/Out)
*Loosen screw *Move door up or down as required *Tighten screw	*Turn screw clockwise to move left *Turn screw counterclockwise to move right	*Turn screw clockwise or counterclockwise to move inward or outward

Metal Double Wall Drawers:

To remove cabinet drawers, locate the release mechanism located at the bottom of the drawer box and lift up and out.

To adjust, remove the cover cap to reveal the mechanisms and follow the steps below:

Vertical (Up/Down) Adjustment	Horizontal (Left/Right) Adjustment	Tilt Adjustment
*Turn wheel forward or backward to move up or down	*Turn screw clockwise or counterclockwise to move left or right	Gallery rail only: turn gallery rail clockwise or counterclockwise to adjust drawer front tilt

Avante Metal Double Wall Drawers (Exclusive to AyA+):

To remove cabinet drawers, lift the drawer box up and out.

To adjust, slide drawer cover back (for vertical and horizontal adjustments) or remove the top cover panel (for tilt adjustment) to reveal the mechanisms and follow the steps below:

Vertical (Up/Down)	Horizontal (Left/Right)	Tilt Adjustment
*Turn screw clockwise or counterclockwise to move up or down	*Turn screw clockwise or counterclockwise to move left or right	*Turn screw clockwise or counterclockwise to adjust drawer front tilt

Wood & Wood Dovetail Drawers:

To remove cabinet drawers, locate the release mechanism located at the bottom of the drawer box and lift up and out.

To adjust, follow the steps below:

Vertical (Up/Down) and Horizontal (Left/Right)	Additional Vertical (Up/Down)
*Locate screws inside of drawer box which secure the drawer front *Loosen screws, move the drawer front horizontally (left or right) and vertically (up and down) as required *Tighten screw	*Locate catches on underside of drawers *Turn wheel clockwise or counterclockwise to move up or down

For complete and most current adjustment information, please visit: <https://www.ayakitchens.com/product/support/productcare.html>